

SILVERLINE

Free Standing Cabinets



- SILVERLINE cabinets have four side openable, lockable and easily removable covers.
- The rear and side covers are made by DKP sheet and the front side is made by 4 mm thick, impact resistant, tempered and smoked-colored glass which is supported by metal frames. All covers can be opened up to 135 degree.
- The main frame is 1,5 mm, side and rear covers are 1,2 mm steel sheet.
- The frame and corner profiles have a screwed structure at the exterior surface.
- Ventilation is provided by cooling units with 2 or 4 fans
- At the top part there is a protective structure that prevent to entrance of dust and foreign matters.
- There are four 19" mounting profiles and these profiles can move deep within the cabinet.
- At the bottom part of the cabinets there is a brushed cable entry
- Load capacity is 400 kg.
- It has the option of using wheeled and fixed legs.
- Painted by impact-resistant, high strength, electrostatic Ral 9005 texture black color.

19" 600 x 600 SILVERLINE Cabinet Genişlik - Width: 600 mm / Derinlik - Depth: 600 mm

Order No	U	h	H	KG
FORM SIL-26U6060	26	1158	1386	60

U: Unit (1U=44,45mm) / h: İç Yükseklik - Inside Height (mm) / H: Tekerlek Dahil Dış Yükseklik - Outside Height (mm)