

## COSMOLINE

### Free Standing Cabinets



- COSMOLINE cabinets have four side openable, lockable and easily removable covers.
- The rear and side covers are made by DKP sheet and the front side is made by 4 mm thick, impact resistant, tempered and smoked-colored glass which is supported by metal frames
- The main frame is 1,5 mm, side and rear covers are 1,2 mm steel sheet.
- The frame and corner profiles have nested structure and this structure provides high strength.
- Ventilation is provided by cooling units with 2,4 or 6 fans.
- There are four 19" mounting profiles and these profiles can move deep within the cabinet.
- Mounting profiles have U markings that facilitate the mounting process.
- At the bottom part of the cabinets there is a sliding and dust-protected brushed cable entry. In 600x1000 , 800x800 and 800x1000 cabinets, these entries are available in two locations, from bottom to top.
- It has the option of using wheeled and fixed legs.
- Painted by impact-resistant, high strength, electrostatic Ral 9005 texture black color.
- All test procedures have been carried out and has ROHS, CE, EN 61587-1 standards.

#### 19" 800 x 800 COSMOLINE Cabinet Genişlik - Width: 780 mm / Derinlik - Depth: 780 mm

| Order No         | U  | h    | H    | KG  |
|------------------|----|------|------|-----|
| FORM CSM-32U8080 | 32 | 1425 | 1653 | 102 |

U: Unit (1U=44,45mm) / h: İç Yükseklik - Inside Height (mm) / H: Tekerlek Dahil Dış Yükseklik - Outside Height (mm)